



INSTALLATION

REMOVE 2-WAY SCREW [A] (M4 X 0.7 X 18mm) TO RELEASE THE MOUNTING RECTANGULAR CANOPY [D].

- 1 - **INSTALLATION ON 4" JUNCTION BOX**
INSTALL STANDARD 4" JUNCTION BOX (SUPPLIED BY OTHERS). PLACE THE UNIVERSAL CROSSBAR [B], AND MAKE ALL WIRING CONNECTIONS.
- 1A- **DIRECT INSTALLATION (BX, FLEXIBLE ARMoured CABLE)**
ATTACH THE FLEXIBLE ARMoured CABLE FITTING AND CABLE (SUPPLIED BY OTHERS) TO THE MOUNTING CANOPY [D]. MOUNT IT TO THE WALL WITH 2-WAY #8 MOUNTING SCREW [F] & ANCHOR [G] AND MAKE ALL WIRING CONNECTIONS. GO DIRECTLY TO STEP 3.
- 2 - **INSTALL SQUARE CANOPY PLATE [C] AND THE MOUNTING RECTANGULAR CANOPY [D] TO THE JUNCTION BOX USING 2-WAY MOUNTING SUPPLIED SCREWS [E]. SECURE IT INTO PLACE WITH 2-WAY #8 MOUNTING SCREW [F] & ANCHOR [G].**
- 3 - **ASSEMBLE THE BALLAST HOUSING [H] TO THE MOUNTING RECTANGULAR CANOPY [D] WITH 2-WAY SCREW [A]. USE [A*] FOR LED ONLY.**
- 4 - **PUT GLASS SHADE [I] IN PLACE AND SECURE WITH 4-WAY SUPPLIED SCREWS [J].**

INSTALLATION

AVANT DE COMMENCER, DÉVISSER LES 2 VIS [A] (M4 X 0.7 X 18mm) POUR LIBÉRER LA STRUCTURE DE CANAPÉ RECTANGULAIRE [D].

- 1 - **INSTALLATION DE LA BOÎTE ÉLECTRIQUE 4"**
INSTALLER LA BOÎTE DE JONCTION STANDARD 4" (NON-INCLUSE). ASSEMBLER LA PLAQUE UNIVERSELLE [B] ET FAIRE LA CONNEXION DES FILS.
- 1A- **INSTALLATION DIRECTE (BX, CABLE FLEXIBLE ARMÉ)**
INSTALLER LE CONNECTEUR POUR CABLE ARMÉ ET LE CABLE (NON-INCLUSE) SUR LA STRUCTURE DE CANAPÉ [D]. VISSER L'ENSEMBLE DE STRUCTURE DIRECTEMENT AU MUR GRÂCE AUX VIS DE MONTAGE #8 [F] & AUX CHEVILLES [G] ET FAIRE LA CONNEXION DES FILS. ALLER DIRECTEMENT À L'ÉTAPE 3.
- 2 - **FIXER LA PLAQUE CARRÉE [C] ET LA STRUCTURE DE CANAPÉ RECTANGULAIRE [D] SUR LA BOÎTE ÉLECTRIQUE À L'AIDE DES (2) VIS DE MONTAGE FOURNIES [E]. SÉCURISER L'ENSEMBLE DE STRUCTURE DIRECTEMENT AU MUR GRÂCE AUX VIS DE MONTAGE #8 [F] & AUX CHEVILLES [G].**
- 3 - **MONTÉ LE KIT ÉLECTRIQUE SUR LA STRUCTURE DE CANAPÉ RECTANGULAIRE [D] À L'AIDE DES 2 VIS [A]. LES RONDELLES [A*]- LED SEULEMENT.**
- 4 - **DÉPOSER L'ABAT-JOUR EN VERRE [I] AFIN DE FERMER L'ENSEMBLE DE MONTAGE ET SÉCURISER LE TOUT À L'AIDE DE (4) VIS FOURNIES [J].**